



NOTE:
This camera is designed with water resistance technology only. DO NOT submerge in water for a long period time. It will damage the camera and become inoperable.

WARNING:
Connect the camera's power wire to reverse wire only. DO NOT connects to constant or ignition power. If the camera is on all the time it will shorten the camera's life or possible burn out the camera.