


Connect the Black & Green Wires Together  
For Normal Image



**NOTE:**

This camera is designed with water resistance technology only. These camera are not designed to be submerged in water. If any changes to be make on the camera. You must first power down the camera then make your changes. After you finished your changes power up the camera again, the camera will automatically save the programming

**WARNING:**

Connect the camera's power wire to reverse wire only. DO NOT connect to constant or ignition power. The camera is not designed for continuous viewing